

Feller Germany



CM 21 BK

**Coffee
Maker**

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electrical shock and/or personal injury.

IMPORTANT SAFEGUARDS



1. Please read these instructions carefully before using the appliance;
2. Check that your mains voltage accord with the nameplate on the appliance;
3. Never leave the appliance unsupervised when in use. Keep out of reach of children or incompetent persons;
4. Only use the appliance for domestic purposes and in the way indicated in these instructions;
5. Never use the appliance near hot surfaces;
6. Unplug unit from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance;
7. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner, return appliance to after sale service center of Feller, for examination ,repair or adjustment;
8. Never use the appliance outside and always place in a dry environment;
9. Never use accessories which are not recommended by Feller. They could constitute a danger to the user and risk to damage the appliance.
10. Never move the appliance by pulling the cord. Make sure the cord cannot get caught in any way. Do not wind the cord around the appliance and do not bend it.
11. Stand the appliance on a table or flat surface.
12. Only use fresh(potable)and cold(moderate)water.
13. Make sure the cord never comes into contact with the hot parts of the appliance.
14. Never touch the hot parts of the appliance. Only touch the plastic parts and the cup by the handle.
15. Be careful not to get burned by the steam evaporating form the coffee filter.
16. Never use the appliance if the cup shows any signs of cracks. Only use the cup with this appliance. Handle with care as the ceramic is very fragile.
17. Never use your coffee machine without water in it.
18. Always attach plug to appliance first ,then plug cord into the wall outlet. To disconnect turn any control to "off", then remove plug from wall outlet.
19. Do not use coffee machine with a damaged outlet.
20. Do not forget that the temperature of the coffee prepared is high. Handle with care your coffeepot to avoid any risk of splashes.

- 21.** Any examination, repair, or adjustment for the appliance should be made by after sale service center of Feller.
- 22.** Save this instruction for future use.
- 23.** Never immerse the appliance in water or any other liquid.

OPERATION

- 1.** Uncover the top cover and fill clean water to required level.
- 2.** Put adequate quantity of coffee powder or tealeaves in the filter cone.
- 3.** Place the cups on the drip plate.
- 4.** Place the tundish with the filtercone in the tundish support.
- 5.** Close the top cover.
- 6.** Switch on, the indicator lamp will light up and the machine begin working.
- 7.** After boiling, when no water in tank, the coffee is ready.

TECHNICAL IN FORMATION

Input voltage.....	230 VAC
Power.....	450 W
Container.....	0.24L

CLEANING

- 1.** Do not forget to remove the plug from the socket before cleaning the appliance.
- 2.** Wipe outside with soft dry cloth when coffee machine is wet, never use metal polish.
- 3.** The removable items should be washed in hot soapy water. Rinse them before Fixing.
- 4.** Wash the filter and cups.
- 5.** Never use a dishwasher to clean any parts from the machine.
- 6.** Put the coffee maker in a dry and not very hot place.

ENVIRONMENT FRIENDLY DISPOSAL

You can help protect the environment!
Please remember to respect the local regulations : hand in the non-working electrical equipments to an appropriate waste disposal center



- از خطر ریزش هرگونه مایعات، دستگیره‌ی کتری قهوه را با دقت بردارید.
۲۱. هرگونه بررسی، تعمیر یا تنظیم دستگاه باید توسط مرکز خدمات پس از فروش فلرانجام گیرد.
 ۲۲. برای استفاده آینده، این دفترچه را نزد خود نگه دارید.
 ۲۳. هرگز دستگاه را در آب یا هر مایع دیگر قرار ندهید.

روش استفاده

۱. پوشش روئی دستگاه را بردارید و مخزن را تا سطح مورد نیاز با آب تمیز پر کنید.
۲. به مقدار مناسب پودر قهوه یا چای خشک در صافی مخروطی شکل بریزید.
۳. فنجان‌ها را در صفحه‌ی قطران بگذارید.
۴. قیف را با صافی مخروطی شکل در تکیه‌گاه قیف قرار دهید.
۵. روکش روئی را ببندید.
۶. دستگاه را روشن کنید. در این حالت چراغ نشان‌گر ظاهر شده و دستگاه کار خود را شروع خواهد کرد.
۷. بعد از جوشیدن و زمانی که آبی در مخزن نباشد، در آن لحظه قهوه آماده است.

اطلاعات فنی

ولتاژ/ فرکانس: ۲۴۰-۲۲۰ ولت - ۵۰/۶۰ هرتز
توان: ۴۵۰ وات
حجم مخزن: ۲۴۰ سی‌سی

روش تمیزکاری

۱. فراموش نکنید قبل از تمیز کردن دستگاه، دوشاخه را از پریز جدا کنید.
۲. قسمت بیرونی دستگاه را با دستمال نرم و مرطوب تمیز کنید. هرگز از براق کننده‌های فلزی استفاده نکنید.
۳. لوازم جداشونده باید در آب داغ و صابون شسته شوند. قبل از نصب مجدداً آنها را با آب بشوئید.
۴. صافی و فنجان‌ها را بشوئید.
۵. برای تمیزکاری لوازم دستگاه، هرگز از ماشین ظرف‌شوئی استفاده نکنید.
۶. قهوه‌ساز را در محیط خشک و نه چندان گرم نگاه‌داری کنید.

روش بازیافت سازگار با محیط‌زیست



می‌توانید با کمک به محیط‌زیست از آن محافظت کنید. لطفاً به قوانین محلی احترام بگذارید. دستگاه برقی غیر قابل استفاده خود را به یکی از مراکز مناسب بازیافت زباله تحویل دهید.

پیش از استفاده از وسایل برقی، باید هشدارهای اولیه ایمنی را مدنظر داشت:

هشدارهای مهم ایمنی



۱. لطفاً قبل از استفاده از این دستگاه به دقت این دفترچه را بخوانید.
۲. ولتاژ برق شبکه محل مورد استفاده را با ولتاژ درج شده روی دستگاه بررسی کنید.
۳. زمانی که دستگاه روشن است، هرگز آن را بدون نظارت رها نکنید. دستگاه را دور از دسترس کودکان و افراد بی مهارت قرار دهید.
۴. از این دستگاه فقط برای مصارف خانگی و به روشی که در این دفترچه ذکر می شود، استفاده کنید.
۵. هرگز از دستگاه در مجاورت سطوح داغ استفاده نکنید.
۶. زمانی که از دستگاه استفاده نمی کنید یا قصد تمیز کردن آن را دارید، دوشاخه را از پریز جدا کنید.
۷. در صورتی که سیم برق یا دوشاخه ی دستگاه آسیب دیده است یا دستگاه خوب کار نمی کند یا به طریقی آسیب دیده است، آن را برای رسیدگی، تعمیر یا تنظیم به نزدیک ترین مرکز خدمات پس از فروش شرکت فلر انتقال دهید.
۸. هرگز از دستگاه در محیط های روباز استفاده نکنید و آن را در جای خشک نگه داری کنید.
۹. هرگز از لوازم جانبی که فلر آن را توصیه نمی کند، استفاده نکنید. این لوازم ممکن است به کاربر و دستگاه آسیب وارد کند.
۱۰. هرگز جریان برق دستگاه را با کشیدن سیم قطع نکنید. مطمئن شوید در هنگام کار، سیم در هیچ حالتی آسیب نمی بیند. سیم را دور دستگاه نیچید و آن را خم نکنید.
۱۱. دستگاه را روی میز یا سطح صاف قرار دهید.
۱۲. برای استفاده از دستگاه فقط آب آشامیدنی و ملائم مصرف کنید.
۱۳. در هنگام استفاده مطمئن شوید سیم برق با قسمت های داغ دستگاه تماس ندارد.
۱۴. در هنگام استفاده هرگز به قسمت های داغ دستگاه دست نزنید. و فقط با دستگیره، قسمت های پلاستیکی و فنجان را لمس کنید.
۱۵. مراقب باشید در تماس با بخار تبخیر شده از صافی قهوه نسوزید.
۱۶. در صورتی که در فنجان آثار شکاف یا ترک خوردگی مشاهده کردید، هرگز از آن استفاده نکنید.
۱۷. هرگز بدون آب از قهوه ساز استفاده نکنید.
۱۸. برای استفاده از دستگاه، ابتدا دو شاخه را به دستگاه سپس به پریز وصل کنید. برای قطع کردن، ابتدا همه ی دکمه ها را در وضعیت خاموش قرار داده سپس دوشاخه را از پریز جدا کنید.
۱۹. اگر سیم دستگاه آسیب دیده است از آن استفاده نکنید.
۲۰. فراموش نکنید که در مرحله آماده سازی، دمای قهوه ساز بالا است. برای جلوگیری

Feller Germany



CM 21 W



فزهوساز