

Feller

User's Manual

Citrus Squeezer



CS 852 S

Citrus Squeezer

Important safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following

1. Read all instructions before operating.
2. Remove the mains plug from the wall socket outlet, if a disturbance occurs
After use if the citrus juicer is out of use for a prolonged period of time
Before cleaning the citrus juicer before removing and inserting the pressing cones
Always pull the plug not the cord.
3. Caution material damage.
4. If you apply too much pressure to the cone while juicing the motor may seize.
5. Keep the connection for placing the juicer.
6. Important information for placing the juicer.
7. Place the juicer on a level surface that will not be harmed by splashes of juice as splashing cannot always be avoided. The surface should be easy to clean.
8. DO NOT stand the juicer on hot surfaces, such as hotplates or near naked flames.
9. Your citrus juicer is equipped with suction feet. The suction feet will adhere to any smooth surface. For them to adhere well, the surface must be flat and also free of dust or grease. The suction feet cannot adhere to a textured surface. Slightly moisten the suction feet before you press them onto the surface.
10. Do not fix the suction feet to sensitive surfaces. Some paints or synthetic coating may react adversely with the material of the suction feet and soften them. This could cause them to leave marks.
11. Never use abrasive or caustic cleaning products, as these may damage the surfaces.
12. To protect against electrical shock, do not immerse cord, plug or appliance itself in water or other liquids.
13. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
14. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
15. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
16. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

17. Do not store any materials other than manufacturers recommended accessories in this unit when not in use.

18. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Before first use

1. Danger: Keep the packaging material away from children .they could suffocate.
2. Unpack the citrus juicer and remove all of the packaging.
3. Material examines the juicer for visible damage and check that all of the parts are present.
4. You should clean the appliance before using it for the first time.
5. Wipe the motor base with a damp cloth.
6. Before using the juicer for the first time, rinse the cones, strainer, juice container and transparent dust lid with warm water and a few drops of washing-up liquid.

Operation

1. Setting up the juicer.
- 2 Stand the appliance on an even surface that is easy to clean.
3. Unwind the power cord – to the length you require – from the cord storage compartment (underneath the juicer). Make sure that the cord is correctly.
4. Connect the mains plug to a AC230V,50Hz socket outlet.

Selecting accessories

1. Depending on the size of the fruit you are juicer, you can use the large or the small cone.
2. The large cone is suitable for juicing small citrus fruit, such as grapefruit, oranges etc.
3. The small cone is suitable for juicing small citrus fruit, such as lemons, limes etc.
4. Fit the small juicing cone directly onto the drive shaft.
5. If you wish to use the large cone, fit the small cone onto the drive shaft. Then fit the large cone over the top of the small cone.
6. You must feel the notches in the large cone clip into place over the stirring wings on the small cone.
7. To separate the cones, pull the large cone up and off.

Juicing

Caution: if you apply too much pressure to the juicing cone, the motor may seize.

1. Remove the transparent dust lid.
2. Fit the appropriate cone onto the drive shaft.
3. The juice appropriate cone onto the drive shaft.
 - a) If you wish to collect the juice in the container, press the spout upwards to close it.

- b) If you want the juice to run straight into a glass, press the spout downwards to open it and place a stand under it.
4. Cut a citrus fruit in half and press the cut end of one fruit half onto the cone. The juicer switches on automatically when you press the fruit down and the cone starts to turn. The juicer automatically switches off as soon as you reduce pressure on the cone. The cone scrapes the pulp out and squeezes the juice from the fruit. The juice flows through the strainer into the juice container from where it can run into a glass (the spout must be open). The strainer keeps back thick pulp and seeds.
5. To maximize the quantity of juice extracted from a fruit, press a fruit onto the cone several times.

After use

1. Remove cone, strainer, juice container and drive shaft from the appliance and clean them.
2. Unplug the appliance.

Juicing advice

1. Citrus fruit juices should be consumed immediately and never stored in a metal container.
2. Citrus juices are ideal for mixing. For example, you can mix orange juice with lemon juice for an extra vitamin C kick.
3. Freshly squeezed juice gives cocktails a particularly tangy twist and better flavor. Lemon juice is also delicious in hot tea and additionally helps you build up your defenses when you have a cold.

Cleaning

Danger:

1. Unplug the citrus juicer before you clean it.
2. The motor base must not be immersed in water or other liquids or held under running water as this could give you an electric shock.
3. The juicing cones, strainer and juice container can go in the dishwasher.
4. Wipe the motor base with a damp cloth.
5. If you use the spout on the juice container frequently, pulp may build up in the spout. Therefore clean the spout after each use.

Technical specifications

Model: CS 852 S

Voltage: 220-240V~, 50/60Hz

Power: 85 W

Fault/remedy.

1. Motor won't start
2. Motor stops running while juicing
3. Although the spout is closed, juice still drips out
4. Is the mains plug connected properly to the socket outlet?

5. Are you pressing on the cone too hard?
6. Are there any bits of pulp left in the spout?

Disposal

Meaning of crossed – out wheeled dust bin: DO not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact you local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being, when replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.

We reserve the right to make amendments.

مشخصات فنی دستگاه

مدل: CS 852 S

ولتاژ: ۲۲۰-۲۴۰ ولت، ۵۰-۶۰ هرتر

توان: ۸۵ وات

اشکال	برطرف کردن اشکال
عدم کارکردن موتور	از اتصال درست و کامل دوشاخه به پریز برق اطمینان حاصل نمایید.
توقف عملکرد موتور، در هنگام کار با دستگاه	از عدم وجود فشار بیش از حد بر روی لوله مخروطی دستگاه، مطمئن شوید.
نشت مایع از لوله، حتی در حالی که بسته است.	اطمینان یابید که مجراها و لوله دستگاه، کاملاً تمیز بوده و تفاله‌ای درون آنها گیر نکرده باشد.

گزینش ابزار جانبی مناسب

۱. با توجه به اندازه (بزرگی و کوچکی) میوه‌ای که قصد آب‌گیری آن را دارید، می‌توانید از مخروطی ویژه بزرگ یا کوچک دستگاه، استفاده کنید.
۲. مخروطی بزرگ، برای مرکبات بزرگ‌تر، هم‌چون پرتقال یا گریپ فروت مناسب بوده و مخروطی کوچک، برای میوه‌هایی کوچک‌تر هم‌چون انواع لیموها مناسب است.
۳. مخروطی آب‌گیری را باید مستقیماً بر روی میله گردان قرار دهید. در صورتی که از مخروطی بزرگ استفاده می‌کنید، باید نخست مخروطی کوچک و سپس مخروطی بزرگ را بر روی میله گردان بگذارید و مطمئن شوید که مخروطی بزرگ کاملاً در جای درست قرار گرفته باشد.
۴. برای بازکردن مخروطی‌ها، مخروطی بزرگ را به سوی بالا کشیده و آن را جدا کنید.

روش کار با دستگاه

هشدار: در صورت واردکردن فشار بیش از حد به دستگاه، موتور آن گیر کرده و یا بسیار کند کار خواهد کرد.

۱. گرد و غبار موجود بر روی دستگاه را بزداييد.
 ۲. دکمه روشن/ خاموش کردن دستگاه را بر روی موقعیت روشن (ON) بگذارید.
 ۳. مخروطی مورد نظر را بر روی میله گردان نصب نمایید.
 ۴. مخزن مناسب را نیز بر روی میله گردان بگذارید.
- أ) چنان‌چه مخزن خود دستگاه را مورد استفاده قرار می‌دهید، لوله خروج آب را به سوی بالا فشار دهید تا بسته شود.
- ب) چنان‌چه می‌خواهید آب‌میوه به‌طور مستقیم درون لیوان ریخته شود، باید لوله را به سمت پایین بکشید تا باز شود و سپس ظرف مورد نظر را زیر آن قرار دهید.
۵. میوه را به دو نیمه برش دهید، یک نیمه آن را بر روی مخروطی گذاشته و به کمک درپوش آن را به آرامی فشار دهید؛ دستگاه با این فشار وارد، به‌طور خودکار آغاز به کار کرده و با کم‌شدن یا قطع شدن آن، خاموش خواهد شد.
 ۶. برای آب‌گیری بهتر، می‌توانید میوه را چندین بار بر روی مخروطی گذاشته و آب آن را بگیرید.

پس از استفاده

۱. تمامی اجزای دستگاه را جدا کرده و تمیز کنید.
۲. دوشاخه دستگاه را از پریز برق بیرون بکشید.

تمیز کاری دستگاه

۱. برای انجام هرگونه عملیات تمیز کاری، نخست باید دوشاخه دستگاه را از پریز برق خارج نمایید.
۲. هرگز موتور دستگاه را درون آب فرو نبرید یا آن را زیر شیر آب نشویید؛ این کار موجب برق‌گرفتگی خواهد شد.
۳. مخروطی‌های آب‌گیری، صافی و مخزن دستگاه، کاملاً قابل شستشو در ماشین ظرف‌شویی هستند.
۴. برای تمیز کردن موتور دستگاه، از دستمالی نمدار و تمیز استفاده نمایید.
۵. پس از هر بار استفاده، برای پرهیز از خشک‌شدن تواله میوه‌ها بر روی دستگاه، حتماً آن را بشویید.

توجه به نکات ایمنی زیر در هنگام استفاده از هر گونه دستگاه الکتریکی، امری حیاتی است.

۱. پیش از به کارگیری دستگاه، این دفترچه راهنما را به طور کامل و با دقت مطالعه نمایید.
۲. در صورت آسیب دیدگی دستگاه، عدم استفاده از دستگاه برای مدتی طولانی، یا در هنگام تمیزکاری آن، توصیه می شود که حتماً دوشاخه را از پریز برق خارج کنید.
۳. وارد کردن فشار بیش از حد به درپوش در هنگام استفاده، به موتور دستگاه نیز فشار وارد کرده و منجر به کند کارکردن آن خواهد شد.
۴. همیشه از دستگاه بر روی سطحی صاف و پایدار و خشک استفاده کنید. آن را هرگز بر روی اجاق گاز یا برقی یا در نزدیکی آن‌ها یا هر گونه سطوح داغ دیگری قرار ندهید.
۵. دستگاه شما مجهز به پایه‌ای چسبنده به سطح است، که پایداری آن بر روی سطح را افزایش می‌دهد. توجه داشته باشید، که سطح زیر پایه باید تمیز و بدون گرد و خاک باشد. این پایه هم‌چنین به سطوح پارچه‌ای نمی‌چسبد.
۶. دستگاه را نباید بر روی سطوح حساس قرار دهید، زیرا که پایه آن سبب لگه‌دار شدن سطح می‌شود.
۷. هرگز برای تمیز کردن دستگاه، از مواد شوینده و وسایل نوک تیز استفاده نکنید، زیرا این کار به سطوح آن آسیب می‌رساند.
۸. برای جلوگیری از برق‌گرفتگی، از تماس سیم برق، دوشاخه و خود دستگاه با آب، خودداری نمایید.
۹. برای افرادی (کودکان) که از لحاظ جسمی، حسی و ذهنی ناتوان هستند، یا تجربه و دانش کافی برای کار با این دستگاه را ندارند، استفاده از آن، در نظر گرفته نشده است؛ مگر با نظارت و آموزش دستورات عملی، توسط فردی که مسئولیت آن‌ها را برعهده دارد.
۱۰. پس از اتمام استفاده و پیش از انجام هرگونه عملیات تمیزکاری، باید دوشاخه دستگاه را از برق بیرون کشیده و برای جداکردن قطعات آن تا خنک‌شدن کامل دستگاه صبر کنید.
۱۱. در صورت آسیب دیدگی دوشاخه یا سیم برق دستگاه، هرگز از آن استفاده نکنید. دستگاه را به یکی از مراکز مجاز خدمات ببرید، تا توسط افراد ماهر و باتجربه تعمیر گردد.
۱۲. استفاده از هرگونه ابزاری به‌جز ابزار و لوازم اصلی خود دستگاه (ساخته‌شده توسط کارخانه سازنده)، توصیه نمی‌شود و هم‌چنین منجر به آسیب دیدگی دستگاه خواهد شد.

پیش از استفاده:

۱. هشدار: این دستگاه و اجزای آن را از دسترس کودکان دور نگه دارید.
۲. جعبه بسته‌بندی دستگاه را باز کرده و تمامی اجزای آن را بیرون آورید.
۳. پس از بازکردن بسته‌بندی دستگاه، از سالم بودن تمامی اجزای آن اطمینان حاصل نمایید.
۴. پیش از نخستین استفاده از دستگاه، تمامی اجزای آن را تمیز کنید.
۵. برای تمیزکاری پایه موتور از یک پارچه نمدار و تمیز استفاده نمایید.
۶. پیش از نخستین بار استفاده، شستن و تمیزکردن درپوش، صافی، و مخزن دستگاه ضروریست.

راه‌اندازی دستگاه

۱. اجزای دستگاه را به هم متصل نمایید (دستگاه را سرهم‌بندی کنید).
۲. دستگاه را بر روی سطحی صاف و پایدار قرار دهید.
۳. میزان درازای سیم برق آن را تنظیم کنید.
۴. دوشاخه دستگاه را به پریز برق وصل نمایید.

Feller®

دفترچه‌ی راهنما

آب مرکبات گیری



CS 852 S

Citrus Squeezer